



NOTES:

1. THICKNESS OF AGGREGATE BASE WILL VARY WITH SUBGRADE CONDITIONS AND CLIMATE. COLDER CLIMATES MAY REQUIRE THICKER BASES.
2. PAVERS SHOULD BE PLACED ON A CEMENT-TREATED BASE IF SOIL IS EXTREMELY WEAK OR CONSTANTLY SATURATED.
3. CONSULT SPECIFICATIONS FOR BASE MATERIALS, SUBGRADE SOIL AND BASE COMPACTION.
4. PLASTIC, STEEL OR ALUMINUM EDGING MAY BE USED.

RESIDENTIAL DRIVEWAY WITH CONCRETE OR STONE CURB